

parts2clean 2005

New ultrasonic cleaning tank for industrial use

With the SONOWAVE, Weber Ultrasonics is set to present a new ultrasonic cleaning tank at this year's parts2clean trade fair. The cleaning tank has been specially designed for industry and maintenance applications and is extremely robust, as it is made entirely of stainless steel. The fact that the control elements are not located on the cleaning tank itself, but are rather integrated in the external ultrasonic generator, is a further plus. This separated arrangement offers reliable protection from moisture for the electronics, and allows heating, time and temperature to be ergonomically controlled and monitored from the operator's workplace.

The cleaning tanks are equipped with energy saving heat insulation and are also sound-insulated. The base of the new SONOWAVE is tapered slightly toward the drain, ensuring that the tank can be fully emptied. Weber Ultrasonics, one of the few manufacturers of ultrasonic components to have ISO certification, offers the new SONOWAVE cleaning tanks in four models – with volumes from 40 to 200 liters and heating from 1.5 to 9 kW.

Weber Ultrasonics GmbH, D-76307 Karlsbad-Ittersbach

